

Read First

Important information to help you set up
your new ēno interactive whiteboard inside.

Step 1: Replace the battery in your ěno™ stylus with a longer-life Lithium battery



- A. Replace the battery in the ěno stylus with one of the two Lithium batteries included in this package. Although you can use Alkaline batteries with ěno, Lithium batteries will ensure much longer battery life.
- B. Remember to replace the cap on your stylus when you are not using it to conserve battery life. This is the single most important step to maximize battery life in your stylus.

Step 2: Pairing instructions

Note: New support videos available:

For step-by-step instructions on installing the PolyVision driver and connecting your ěno stylus to your computer (both automatically and manually), please review the support videos available at <http://support.polyvision.com/videos>.

Option 1:

**Use PolyVision's Bluetooth® adapter.
(Recommended)**

Choose this option to automatically pair the ěno stylus to your system when you install the PolyVision driver for the first time.

Step 1: Install the PolyVision driver, using the CD that was included in your accessory kit. Click on the red X next to ěno, to access a drop down menu. Select *This feature will be installed on your local hard drive*, and click *Next*.

Step 2: Do not plug in the Polyvision Bluetooth adapter yet. Keep the cap on the ěno stylus. Begin the PolyVision driver setup.

Step 3: At the end of the install, you will be prompted to auto-pair the ěno stylus. Choose *OK* to begin this process.

Step 4: You will be prompted to plug in the PolyVision Bluetooth adapter. Plug it into one of the empty USB ports in the computer and continue.

Step 5: The system may appear idle for several minutes while the Bluetooth drivers are loaded. When prompted, take the cap off of the ěno stylus and continue.

Step 6: When the pairing is complete, a message will appear that says *The ěno stylus was paired successfully*. Click the *OK* button. You have successfully paired your ěno stylus.

Pairing instructions for re-establishing your connection:

Step 1: Plug in the PolyVision Bluetooth adapter.

Step 2: Click the PolyVision driver icon (looks like a whiteboard), located at the bottom right of your computer.

Step 3: Choose *Configure the PolyVision driver*. When the Configure Options window opens, click the *Hardware* tab.

Step 4: In the Hardware tab, click *Pair Stylus* button.

Step 5: The system may appear idle for several minutes while the Bluetooth drivers are loaded. When prompted, take the cap off of the ěno stylus and continue.

Step 6: When the pairing is complete, a message will appear that says *The ěno stylus was paired successfully*. Click the *OK* button. You have successfully paired your ěno stylus.

Option 2:


**Use your existing Bluetooth adapter,
preserving all existing Bluetooth devices.**

When you choose to use your existing Bluetooth device, ěno auto-pairing cannot take place, so the stylus must be manually paired. However, existing Bluetooth devices will not need to be re-paired to your system:

Step 1: Do not plug in the Polyvision Bluetooth adapter. Keep the cap on the ěno stylus. Install the PolyVision driver, using the CD that was included in your accessory kit. Click on the red X next to ěno, to access a drop down menu. Select *This feature will be installed on your local hard drive*, and click *Next*.

Step 2: At the end of the install, you will be prompted to auto-pair the ěno stylus. Choose *OK*.

Step 3: You will be prompted to plug in the PolyVision Bluetooth adapter. Choose *No* to leave your existing Bluetooth drivers installed. Do not plug in the PolyVision Bluetooth adapter.

Step 4: Click the Bluetooth icon  on the computer's control bar – this is the Taskbar on Windows or the Menu bar on the Mac.

Step 5: Choose *Add Device*, or *Setup Bluetooth Devices* from the menu.

Step 6: Follow your computer's instructions to search for devices, removing the cap from the ěno stylus before starting the search.

Step 7: From the list of devices found, select the *ADP-301* device (the ěno stylus).

Step 8: When prompted, enter the passkey (or PIN) number *"0109"* to complete the pairing. You have successfully paired your ěno stylus.



Troubleshooting: tips...and tricks

How do I know when the battery in my ēno stylus is low?

When the battery in your ēno stylus is low, the stylus will exhibit one or several of the following behaviors:

- The LED on the stylus will blink every five seconds.
- The handwriting may appear as broken lines.
- The ēno stylus will fail to pair with your computer.
- The stylus will not be able to make a connection to your computer when you remove the cap.

The auto-pair feature is not working.

- The battery in the ēno stylus needs to be replaced.

If the battery is low, the ēno stylus will not have enough power to complete a pairing operation to the PC. Simply put in a new battery to resolve this problem.

- In Windows, the Microsoft® Bluetooth stack is not being used (auto-pairing only works with the Microsoft Bluetooth stack, standard on a PC).

If you need auto-pairing, remove your existing Bluetooth stack via the control panel Add/Remove program icon, then plug in the PolyVision Bluetooth adapter. Windows will then automatically install the Microsoft Bluetooth stack. You must re-pair your pre-existing Bluetooth devices at this point.

My ēno stylus is no longer connecting to my computer (is not paired).

- The Bluetooth adapter has been moved to a different USB port.
- The ēno stylus has been paired to another computer.

Bluetooth devices were designed with security in mind. When a Bluetooth device is connected to a computer, a unique security ID is generated which takes into account the computer, port and stylus. If any of these change, the connection is broken. Simply re-connect the stylus to the computer and follow the *Pairing Instructions* on the previous page.

I am trying to manually pair, but the ēno stylus is not listed.

- The battery may be too low to pair to the computer.
- The stylus may already be paired to another computer. Follow steps in the section below to re-connect to your computer.

The cap must be removed just before the search for new devices is done. The stylus only stays in its discoverable mode for a short period before it becomes undetectable to computers looking for devices to pair.

How do I pair my ēno stylus with another computer?

When you originally paired the ēno stylus, you paired it to the Bluetooth radio and Bluetooth stack on that computer. Although the stylus can be moved to any computer simply by pairing it to that computer, we recommend un-pairing the stylus from the original computer to avoid confusion. To un-pair the stylus, go to the Bluetooth control panel, choose *Bluetooth* and click on the *ADP-301* icon and click *Remove*. Once you have put the Bluetooth receiver in the new computer, click the *Pair Stylus* button on the Hardware tab in the PolyVision driver to re-pair the stylus.

I still have more questions, who can I contact?

For questions or additional help, please contact PolyVision Customer Service at 800.620.POLY (7659) or support@polyvision.com, available Monday through Friday from 8:00 am to 6:00 pm Eastern.

